

Directions For Use

1. Conduct a complete visual inspection of the member to be clamped, checking for cracks or missing material (knot holes, chamfered edges etc).
2. Place clamp on wood member to be fastened, leaving approximately 1-1/4" of tongue protruding from end of the board. Keeping light pressure on top of the clamp (to assure the clamp is seated properly) start to tighten the screw. When the three cone points and pressure pad come in contact with the board continue to tighten until the three screws are completely imbedded in the framing member. All lumber varies in density and strength. To check for a proper connection, give the clamp a firm tug upward, and if any movement is noticed, continue to tighten.
3. With clamp securely in place, move board to the area of installation. Carefully lower board to its final position. With the board temporarily suspended, complete the required fastening schedule.
4. After finishing the connection, remove clamp.

***** ALWAYS FOLLOW NECESSARY JOBSITE PRECAUTIONS.**

***** NEVER STAND BELOW UNFASTENED JOISTS OR RAFTERS**